



Pos.no.	Part name	Qty
A-01	Riding Seat	1
A-02	Seat Suspension Spring	2
A-03	Nut	23
A-04	Seat Mounting Plate	1
A-05	Flat Washer	4
A-06	Bolt	8
A-07	Spring	1
A-08	Spring washer	4
A-10	Frame Assembly	1
A-11	Reverse Switch Mounting Plate	1
A-12	Axle Side Mounting Plate	1
A-13	Bolt	27
A-14	Bolt	1
A-15	Spring	1
A-16	Bolt	1
A-17	Nut	18
A-18	Fixture assembly	1
A-19	Bolt	2
A-20	Plastic Grip	1
A-21	Governor Assembly	1
A-22	Governor Cable	1
A-23	Gear Selection Plate	1
A-24	Screw	2
A-25	Bolt	2
A-26	Frame seat support plates	1
A-27	Frame seat connecting rods	2
A-28	Seat support bars	2
A-29	Bolt	8
A-30	Turn up the gear plate	1
A-31	left hanging board	1
A-32	Gasket of Cylinder Head	6
A-33	screw	1
A-34	Rear support frame	1
A-35	Reinforcement plates	4
A-36	Bolt	8
A-37	Right connecting plate	1
A-38	Right hanging plate	1
A-39	Step pin	2
A-40	Brake cables	1
A-41	Walking clutch cable	1
A-42	Nut	10
A-43	Brake pedal pads	3
A-44	Brake pedal plate	3
A-45	Brake pedal	1
A-46	Brake pedal	1
A-47	Split Pin	2
A-48	Flat Washer	2
A-49	Foot pedal right fixing plate	1
A-50	Screw	6

A-51	Foot pedal support board	1
A-52	Gasket of Cylinder Head	4
A-53	Fixing plate	1
A-54	Mowing pedal assembly	1
A-55	E-type circlip	2
A-56	Return tension spring	1
A-57	Switch fixing plate	1
A-58	Bolt	1
A-59	Foot pedal left fixed plate	1
A-60	Body cover fixing plate	2
A-61	Bush	3
A-62	Screw	3
A-63	Nut	1
A-64	Rear upper bezel	1
A-65	Safety switch platen	1
A-66	Screw	1
A-67	Wire cards	2
A-68	Rear lower bezel	1
A-69	screw	2
A-70	Trailer retaining plates	1
A-71	Fixed plate	1
A-72	Straw box limit hook	1
A-73	Screw	2
A-74	Flat Washer	2
A-75	Plate	1
B-01	Steering wheel cover	1
B-02	Bolt	1
B-03	Spring washer	1
B-04	Flat Washer	1
B-05	steering wheel	1
B-06	Steering coupling sleeve	1
B-07	Steering wheel bottom cover	1
B-08	Flat Washer	1
B-09	Pin	1
B-10	Pin	2
B-11	Flat Washer	2
B-12	Bolt	14
B-13	platen	1
B-14	Steering axle bushing	1
B-15	Steering shaft suppor (new)	1
B-16	Nut	8
B-17	Bolt	1
B-18	Nut	7
B-19	Handle Cover	1
B-20	Bolt	1
B-21	Handle	1
B-22	Blade clutch lever	1
B-23	Bushings	1
B-24	torsion spring	1
B-25	clutch pull plate assembly	1

B-26	Step bolts	1
B-27	Flat Washer	1
B-28	Split Pin	1
B-29	Bolt	5
B-30	Blade clutch cable	1
B-31	Blade clutch plate	1
B-32	Cutterhead belt brake spring	1
B-33	E-type circlip	1
B-34	Flat Washer	5
B-35	Step pins	1
B-36	Brake cable fixing plate	1
B-37	Hanging orifice plate assembly	1
B-38	Return tension spring	1
B-39	Return tension spring	1
B-40	Bolt	1
B-41	Parking board	1
B-42	Parking tension spring	1
B-43	Screw	1
B-44	Parking pull plate	1
B-45	Parking handle	1
B-46	Front cross member assembly	1
B-47	Steering axle fixing plate	1
B-48	Sleeve	1
B-49	E-type circlip	2
B-50	Steering shaft assembly	1
B-51	Steering tie rod	2
B-52	Steering tie rod bushing	2
B-53	Flat Washer	2
B-54	13-inch wheel assembly	2
B-55	gasket	2
B-56	Small wheel cover	2
B-57	Flat Washer	1
B-58	Bolt	2
B-59	Nut	1
B-60	Split Pin	4
B-61	Nut	4
C-01	Nut	1
C-02	Bolt	1
C-03	T66R battery lanyard	2
C-04	Tie	9
C-05	Charger	1
C-06	wire	1
C-07	wire	1
C-08	Battery	1
C-09	Key switch assembly	1
C-10	JP8 harness	1
C-11	fuse	1
C-12	Motor harnesses	1
C-13	Battery	1
C-14	wire	1

C-15	wire	1
C-16	Switch(normal close)	4
C-17	wire	1
C-18	Screw	2
C-19	TR66 circuit board	1
C-20	wire	1
C-21	Pipe sheath	1
C-22	wire	1
C-23	Switch(normal open)	1
C-24	Pipe sheath	1
C-25	protecting push	1
D-01	The front of the car	1
D-02	screw	24
D-03	Front Left Cover	1
D-04	Screw	17
D-05	Front Right Cover	1
D-06	Front Lower Cover	1
D-07	Seat Base Front Cover	1
D-08	Front Bumper Panel	1
D-09	Left Body Cover	1
D-10	Seat Base Left Cover	1
D-11	Left Connecting Plate	1
D-12	Left Footrest Plate	1
D-13	Right Body Cover	1
D-14	Right Footrest Plate	1
D-15	Right connecting plate	1
D-16	Seat base right cover	1
D-17	Cover	1
D-18	Body cover	1
D-19	Screw	4
D-20	Screw	6
E-01	Fuel Tank	1
E-02	Tank cover	1
E-03	Gasket	8
E-04	Bolt	4
E-05	T66R Gasoline Hose	1
E-06	Clamp	2
E-07	Bolt	2
E-08	Fuel Tank Lower Bracket	1
E-09	Nut	6
E-10	Gasket of Cylinder Head	2
E-11	Fuel Tank Upper Bracket	1
F	Side Ejection Cutting Unit	1
G-01	Handle Cover	1
G-02	Bolt	1
G-03	Handle	1
G-04	pull rod	1
G-05	Pull plate assembly	1
G-06	Split Pin	9
G-07	Flat Washer	3

G-08	Flat Washer	2
G-09	Flat Washer	1
G-10	Nut	1
G-11	Nut	3
G-12	Joint	1
G-13	pull rod	1
G-14	Flat Washer	2
G-15	Bolt	2
G-16	Nut	2
G-17	Bush	1
G-18	Bracket assembly	1
G-19	Bushings	1
G-20	Flat Washer	10
G-21	Blade height adjustment rod	2
G-22	Blade height adjustment rear plate	2
G-23	Pin	9
G-24	Bolt	2
G-25	Spring washer	2
G-26	Flat Washer	2
G-27	Nylon bushings	4
G-28	Rotary shaft	2
G-29	Circlip	2
G-30	Attach the pull plate	2
G-31	Split Pin	5
H-01	Grass Discharge Cylinder	1
H-02	Grass plug	1
I-01	Grass bag front handle	1
I-02	Grass bag rear handle	1
I-03	Grass Bag Top Cover	1
I-04	Screw	8
I-05	Reinforcing rod assembly	1
I-06	Seals	2
I-07	Bolt	6
I-08	Bolt	4
I-09	Upper branch assembly	1
I-10	Screw	6
I-11	Connecting plates	2
I-12	Nut	10
I-13	Grass bag reinforced rod	2
I-14	Lower branch pipe assembly	1
I-15	Fabric bag	1
I-16	Flat Washer	4
J-01	Gasket of Cylinder Head	4
J-02	Exhaust outlet nozzle assembly	1
J-03	Engine	1
J-04	Engine pulley assembly	1
J-05	Engine pulley bracket	1
J-06	Flat Washer	8
J-07	Blade Bolt	1
J-08	Gasket of Cylinder Head	8

J-09	Driveshaft pulley bracket	1
J-10	Nut	3
J-11	Bolt	3
J-12	Swingarm assembly	1
J-13	Tensioner studs	1
J-14	Tensioner	1
J-15	Nut	2
J-16	Handle Cover	1
J-17	Bolt	1
J-18	Handle	1
J-19	Gear lever	1
J-20	Gear lever spring	1
J-21	Gear shift lever assembly	1
J-22	Split Pin	2
J-23	Flat Washer	1
J-24	Flat Washer	1
J-25	ball joint assembly	1
J-26	Nut	1
J-27	Drive Axle Tie Rod (HC)	1
J-28	Bolt	1
J-29	Pin	1
J-30	Side fixing plate for gear shift	1
J-31	Gear lever rod	1
J-32	Bolt	4
J-33	Belt	1
J-34	T66R drive axle assembly	1
J-35	Flat Key	3
J-36	Rear wheel bushings	2
J-37	15-inch wheel assembly	2
J-38	Open retaining rings	4
J-39	Flat Washer	2
J-40	Small wheel cover	2
J-41	Ball Bearing	4
J-42	Lock Ring	2
J-43	Flat Washer	1
J-44	Flat Washer	1
J-45	Right guard	1
J-46	Left guard	1
J-47	Nut	1
J-48	Spring washer	3
J-49	Nut	8
J-50	Walking tensioner	1
J-51	Flat Washer	2
J-52	Lock Ring	1
J-53	gasket	1
J-54	Drive axle pulley assembly	1
J-55	Bolt	1
J-56	Spring washer	1
J-57	Flat Washer	1
J-58	Gear swing arm	1

J-59	Nut	2
K-12	funnel	1
K-13	wrench	1
K-14	wrench	1
K-15	wrench	1
K-16	sleeve	1
K-17	screwdriver	1
K-25	Gasket of Cylinder Head	16.000