



No.	Part name	Qty.
A	crankshaft assy	
1	crankshaft	1
2	half round key	1
3	piston ring-pair	2
4	piston	1
5	ring on piston pin-pair	2
6	needle bearing	1
7	piston pin	1
B	left crankcase assy	
1	left crankcase	1
2	bearing P5	1
3	oil bearing	1
4	round pin	2
5	bolt M5	4
6	flywheel	1
7	nut M8	1
8	bolt M5	2
9	ignator	1
10	ignator cap	1
11	ground lead	1
12	choke cable	1
13	flat gasket	2
14	clutch assy	1
15	wave pad	2
16	screw M8	2
17	side cover	1
18	bolt M5	4
C	right crankcase assy	
1	right crankcase	1
2	bearing P5	1
3	round pin	2
4	paper pad on crankcase	1
5	oil bearing	1
6	flat gasket	1

No.	Part name	Qty.
7	driver plate	1
8	starter assy-easy start	1
9	nut M5	1
9	bolt M5	4
D	cylinder assy	
1	paper pad on cylinder	1
2	cylinder	1
3	ignition plug	1
4	bolt M5	4
5	cylinder cover	1
6	bolt M5	1
E	muffler assy	
1	paper pad on muffler	1
2	muffler	1
3	bolt M5	2
4	bolt M6	2
5	muffler cover	1
6	nut M5	1
F	in-take system	
1	paper pad on in-take pipe	1
2	in-take pipe	1
3	bolt M5	2
4	paper pad on carburetor	1
5	carburetor	1
6	air-filter	1
7	bolt M5	2
8	air-filter sponge	1
9	air-filter cover	1
10	air-filter lock nut	1
G	oil-tank assy	
1	oil-tank cap	1
2	oil-tank assy	1
3	oil-tank holder	1
4	bolt M5	4